



576

GEOFLOW
SECTION

SIMPLE WASTEFLOW HEADWORKS BOX – MANUAL
SCHEMATIC

Not To Scale

06-08 GEOFLOW ?